



Developed in Germany

2002 NEW

COLD VULCANIZING CEMENT

Free of Trichloroethylene

The TRS 2002 NEW cold-vulcanizing adhesive is TRS' system for cold splicing and repairing rubber conveyor belts when a non-flammable product is required. By using TRS 2002 NEW with TRS 1000 M or TRS 1000 TRISO hardeners you can also work in all areas where wear and corrosion protection are needed.

SCOPE

TRS 2002 NEW is a two-component cold vulcanizing adhesive based on polychloroprene rubber (CR) specially designed to bond rubber to rubber, rubber to fabric, rubber to metal, fabric to fabric or metal to fabric in areas that a non-flammable product is required such as in underground mining.

A very important field of application is belt repairing with TRS Diamond Repair Patches and TRS Repair Strips.

PHYSICAL PROPERTIES

| | | | |
|--|---|--|--|
| Basis | ➔ Polychloroprene rubber (CR) | Thermal stability - UNE EN 12964 | ➔ Max. 70°C constant |
| Solvent System | ➔ PERC, DCM | Open Time UNE EN 14022 met 4 - Temp. (15-30°C) | ➔ 15 - 20 minutes |
| Colours | ➔ Dark Grey, White | Open Time UNE EN 14022 met 4 - Temp. (+30°C) | ➔ 8 - 12 minutes |
| Brookfield Viscosity RVT (Sp4, 20 rpm, 20°C) UNE 12092 | ➔ 2700 ± 500 mPa·s | Peel Strength Rubber / Rubber 24h | ➔ 46,7 N/cm |
| Kinematic Viscosity | ➔ 3000 ± 550 cSt | Peel Strength Rubber / Rubber 48h | ➔ 53,3 N/cm |
| Flash Point | ➔ Non-flammable | Pot Life (3% Hardener TRS 1000 E) UNE EN 14022 MET 3 | ➔ Approx. 2 hours at 20°C |
| Oil Resistance | ➔ Excellent | Coverage | ➔ 680 g/m ² with 2 layers or 340 g/m ² per layer |
| Application Temperature | ➔ +10°C to +40°C | Shelf life | ➔ At least 24 months after production date |
| Environmental and Materials Temperature | ➔ +5°C to 45°C (minimum 5° above the dew point) | | |

MIXING INSTRUCTIONS

It is normal that TRS 2002 NEW has a little of sedimentation at the bottom of the can or drum. If so, to be sure that you do not lose this critical component, it is recommend to stir it with the aid of a non-metal and non-round stirrer made of wood or plastic before adding the hardener for at least 2 minutes. Please do not scrape off the spatula that you use to inspect the bottom of the can on the edge of the can losing this material.

Once there is an homogeneous adhesive, usually around 2 minutes stirring, the hardener can be added. It is recommended our TRS Hardener 1000 M (4 - 5% in weight = 20:1) and stir for at least 2 minutes.

STORAGE

Shelf life of unopened containers is 2 years after production date when stored under conditions according DIN 7716. Temperatures below 5 °C can cause a reversible change in the structure of the rubber compound, increasing the viscosity of the glue that can jellify. It is not possible to use the glue under these conditions because the adhesive is so thick that it cannot wet the surfaces to bond. If the cement arrives to this point, the solution is to put the containers at room temperature and let them time to recover, without trying to heat or stir it.

SAFETY



TRS 2002 NEW contains hazardous ingredients: methylene chloride; tetrachloroethylene; rosin; colophony. It is classified under CLP regulation.

For safety instructions for transport, manipulation or storage please read and understand the Material Safety Data Sheet.

PACKAGING SIZES

| TRS 2002 Dark Grey | | | | TRS 2002 White (under request) | | | |
|--------------------|-----------------------------|---------------|------------------------|--------------------------------|-----------------|---------------|------------------------|
| TRS code | Description | Pieces/carton | Quantity/Palet | TRS code | Description | Pieces/carton | Quantity/Palet |
| 302300 | TRS 2002 NEW - 1 Kg | 10 cans | 49 cartons - 490 units | - | TRS 2002 - 1 Kg | 10 cans | 49 cartons - 490 units |
| 302304 | TRS 2002 NEW - 5 Kg | 4 cans | 27 cartons - 108 units | | | | |
| 302320 | TRS 2002 NEW - 200 L/240 Kg | 1 drum | 2 drums | | | | |



COMERCIAL QUÍMICA MASSÓ, S.A. odstepný závod
Předvoje 449/32, Praha 6 162 00 - Česká Republika
Tel.: +420 241 481 798
trs@cqqmasso.com





Developed in Germany

2002 NEW

COLD VULCANIZING CEMENT
Free of Trichloroethylene

APPLICATION

CONDITIONING THE MATERIALS:

Before working on the materials, be sure that you have all of them within the correct temperature and humidity application conditions. If possible, leave materials in the work area to ensure this the day before.

Pay special attention to humidity, it should not exceed 80%, and the temperature of the substrate should be at least 5°C above the dew point to avoid surface condensation of water. Be alert: With temperatures above 30°C the vapor pressure of the product could be high enough to open the can.

SURFACE PREPARATION:

In general, the surfaces to be bonded must be clean, dry, and free of oil, paint, or other kind of contamination. If not, the surfaces must first be cleaned with TRS Cleaning Solvent MEK.

Rubber without bonding layer:

Buff the surface of the rubber with a grinder. The rougher the surface, the better the adhesion. Pay attention to not scorch the rubber. Scorched rubber cannot be glued.

Use only slow running angle grinders for buffing rubber and very rough buffing discs (ex. Silicium carbide - P24). The rougher the buffed surface the larger the surface you are coating with TRS 2002 NEW and, therefore, the better the final adhesion.

Once the surface is polished, remove dust in dry avoiding the application of any kind of solvent after polishing.

Rubber with bonding layer:

Fresh bonding layer: Wash the surface with TRS Cleaning Solvent MEK and let it dry.

Dry bonding layer: Prepare the surface as if it had not bonding layer.

Metal:

Make sure the metallic surface is degreased and free from any contamination. If not, wash the surface with TRS Cleaning Solvent MEK and let it dry.

Buff the surface of the metal using an angle grinder with rough buffing disc (ex. Ceramic - P24). Remove all dust dry.

Fabric:

In this case it depends on each fabric (treatment, weight and weave) but, in general, clean and let it dry.

APPLICATION:

It is strongly recommended to always apply two layers of the product on each surface. The first coat acts as a primer, so it is important to wait until it is totally dry before applying the second coat.

In case of metallic surfaces, it is recommended to apply as a first layer TRS Metal Primer. It is proven that the application of TRS Metal Primer can improve the resistance and the reliability of the bonding.

It is always important to wait at least 1 hour (20°C) before applying the second layer. If possible, it is recommended to apply the first layer the day before.

Apply the product with the help of a brush or a nap roller. It is important to apply a thin and even layer. The scrub-like motion when working with a brush can help us ensure this by avoiding leaving air in the polished surface voids.

The second layer is always glue (also in metal). Apply a uniform and thin layer of glue with the help of a brush. As it has been done the same treatment to both surfaces, drying process will be uniform.

After around 10 minutes, the surfaces are dry to a tack and ready to bond (check it with the back of the hand). Join surfaces and, with a hand-held roller, roll from the centre to the edges applying pressure to bond surfaces together. Working this way eliminates the air avoiding the formation of bubbles on the joint.

Our technical advice - whether verbal, in writing or by the way of trials - is given in good faith but without warranty, and this also applies where proprietary rights of third parties are involved. It does not release you from the obligation to test the products supplied by us as to their suitability for the intended processes and uses
Application use and processing of the products are beyond our control and, therefore, entirely your own responsibility. If, despite this, liability should be established for any damage, it will be limited to the value of the goods delivered by us and used by you. We will, of course, provide products of consistent quality within the scope of our General Conditions of Sale and Delivery.



COMERCIAL QUÍMICA MASSÓ, S.A. odstepný závod
Předvoje 449/32, Praha 6 162 00 - Česká Republika
Tel.: +420 241 481 798
trs@cqqmasso.com

